

Canon

Digitale Video Camcorder
Gebruiksaanwijzing

Nederlands

MD120/MD111 /
MD110/MD101



Mini DV Digital Video Cassette

Inhoud

Voorbereidingen

Basisfuncties

Geavanceerde
functies

Externe
aansluitingen

Aanvullende
informatie

PAL

CEL-003942C

File Name: canon md 120 user manual.pdf

Size: 2577 KB

Type: PDF, ePub, eBook

Category: Book

Uploaded: 10 May 2019, 20:34 PM

Rating: 4.6/5 from 621 votes.

Status: AVAILABLE

Last checked: 14 Minutes ago!

In order to read or download canon md 120 user manual ebook, you need to create a FREE account.

[**Download Now!**](#)

eBook includes PDF, ePub and Kindle version

[Register a free 1 month Trial Account.](#)

[Download as many books as you like \(Personal use\)](#)

[Cancel the membership at any time if not satisfied.](#)

[Join Over 80000 Happy Readers](#)

Book Descriptions:

We have made it easy for you to find a PDF Ebooks without any digging. And by having access to our ebooks online or by storing it on your computer, you have convenient answers with canon md 120 user manual . To get started finding canon md 120 user manual , you are right to find our website which has a comprehensive collection of manuals listed.

Our library is the biggest of these that have literally hundreds of thousands of different products represented.



Book Descriptions:

canon md 120 user manual

The following symptoms may appear if the video heads become dirty even a little. Please read this manual carefully before you use the camcorder and retain it for future reference. Should your camcorder fail to operate correctly, refer to the Troubleshooting table 47. Conventions Used in the Manual IMPORTANT Precautions related to the camcorder's operation. You can display the joystick guide to remind you of the joystick's functions in each operating mode. Recording Playback FOCUS About the Operating Modes The camcorder's operating mode is determined by the position of the manual, indicates that a function is available in the operating mode shown and indicates that the function is not available. When the tape reaches its end, the display changes to ". Charge the battery pack before use. Remove the battery terminal cover before attaching the battery BATT. Open the backup battery cover. Close the cover. NOTES The backup battery has a life span of about a year. Move the lens cover switch down to to open the lens cover. Adjust the viewfinder. Keep the LCD panel closed to use the viewfinder and adjust the dioptic adjustment lever as necessary. Fasten the grip belt. Follow the additional operation guides that will appear on the screen such as the joystick icon. The list of available languages depends on the region where you purchased the camcorder. Language Set A English, German, Spanish, French, Italian, Polish, Romanian, Turkish, Russian, Ukrainian, Arabic and Persian. If necessary, clean the video heads Move the lens cover switch down to to open the lens cover. Holding the lock button pressed down, set the switch to. Previous recordings overwritten by a new recording cannot be recovered. Before you start recording, search for the end of the last recording 24. To protect the tape and video heads, the camcorder will enter the stop mode record pause mode for 4 minutes 30. You can also turn the LCD panel and close it with the screen facing out. <http://huimao.com/upload/instruction-manual-for-blackberry-bold-9900.xml>

- **canon md 120 user manual, canon md 120 user manual pdf, canon md 120 user manual download, canon md 120 user manual instructions, canon md 120 user manual free.**

Holding the lock button pressed down, set the switch to PLAY. POINTS TO CHECK Stop the playback before using this function. For details about how to select an item, refer to Using the Menus FUNC. When activated, the camcorder will switch automatically to the digital zoom when you zoom in beyond the optical zoom range. Changing the brightness of the LCD display does not affect that of the viewfinder or the recordings. Icon of the currently selected FUNC. In such case, focus manually. Reflective surfaces Subjects with low contrast or without vertical lines Fast moving subjects Through wet windows Night scenes POINTS TO CHECK Mode switch BACK FOCUS Adjust the zoom. Other Functions Other Functions Other Functions Data Code The camcorder keeps a data code containing the date and time of recording. The countdown appears on the screen. Open the terminal cover to access. Terminal on the Camcorder Output connection Signal Flow STV250N Stereo Video Cable. Inserting it in the wrong direction can result in damage to the camcorder. Output connection Signal Flow You will need to connect beforehand a commercially available SCART adapter to the SCART terminal on the TV or VCR and then connect the STV250N Stereo Video. Copyright Signals During playback If you try to play back a tape that contains copyright control signals for protection of software, "COPYRIGHT PROTECTED PLAYBACK IS RESTRICTED". Inserting it in the wrong direction can result in damage to the camcorder. Equipment and System Requirements A computer equipped with an IEEE1394 DV terminal or an IEEE1394 DV capturing board. A DV cable Use the optional CV150F 4 pin4 pin or CV250F 4 pin6 pin DV Cable. If you have a

problem with your camcorder, refer to this checklist. Consult your dealer or a Canon Service Center if the problem persists. The tape stops during record pause or playback pause. Recording Problem Image will not appear on the screen. "SET THE TIME ZONE, DATE AND TIME" appears on the screen. <http://dolinaclimata.ru/img/lib/instruction-manual-for-black-u0026-decker-handly-steamer.xml>

Image will not appear on the TV screen. Tape is running, but image will not appear on the TV screen. Editing Problem Cannot record with this camcorder video input from an external video device connected using a DV cable. SUPPORTED HEADS DIRTY, USE Video heads are dirty. Clean the video heads. CLEANING CASSETTE COPYRIGHT PROTECTED You attempted to play back a copyright protected tape. Be careful when closing the LCD panel. Do not leave the camcorder in places subject to high temperatures like the inside of a car under direct sunlight, or high humidity. This is useful when you wish to differentiate between charged and uncharged battery packs. The battery case may break and the battery fluids may cause internal damage. Do not disassemble, heat or immerse the battery in water to avoid the risk of explosion. Stop using the camcorder if condensation is detected. Continued use may damage the camcorder. Condensation may form in the following cases When the camcorder is moved from an airconditioned room to a warm, humid. Consult the Canon Service Center for information on plug adapters for overseas use. Playback on a TV Screen You can only play back your recordings on TVs compatible with the PAL system. This mark identifies genuine Canon video accessories. When you use Canon video equipment, we recommend Canon brand accessories or products bearing the same mark. CCI Service Centre, Unit 130 Centennial Park, Borehamwood, Hertfordshire, WD6 3SE, England Telephone 08702412161 Canon Australia Pty. Ltd. InfoLine 131383 www.canon.com.au Canon New Zealand Ltd. Customer Care 09 489 0470 www.canon.co.nz. Mini Digital Cleaning the Video Heads. Introduction. Digital video camcorders record video signals on the tape in very thin lines. Page 3 3. Important Usage Instructions Introduction Getting to Know the Camcorder Audio Recording and Playback Other Functions Please read this The functions assigned to the joystick change according to the operation mode.

You can Page 8 8 Getting to Know the Camcorder Getting to Know the Camcorder Page 9 Getting to Know the Camcorder 9 Left side view Lens cover switch 21 Back view Viewfinder 16 Page 11 Getting to Know the Camcorder 11. Screen Displays Page 12 12 Getting to Know the Camcorder Preparations Getting Started Page 14 14 Getting Started Page 15 Getting Started 15 Preparing the Camcorder Adjusting the LCD Screen Page 17 Using the Menus 17. LCD Backlight You can set the brightness of the. Page 18 18 Using the Menus First Time Settings Changing the. Page 20 20 First Time Settings. Setting the Date and Time Recording. Recording Movies Playback Page 24 24 Playback. Locating the End of the Last Scene Magnifying the Playback Image. After playing back a tape, use. Page 25 Menu Options Lists 25. Advanced Functions Menu Options Lists Display Setup LCD Brightness, Language, etc. Recording Programs Use the automatic. Page 32 32 Adjusting the Picture Exposure, Focus and Color Page 33 Adjusting the Picture Exposure, Focus and Color 33 Manual Focus Adjustment necessary. Page 34 34 Adjusting the Picture Exposure, Focus and Color Page 35 Audio Recording and Playback 35 Image Effects. You can use the image. Page 36 36 Audio Recording and Playback Page 38 38 Other Functions. FUNC. Add flavor to your recordings. Sound will Page 39 Other Functions 39. Applying External Connections Connecting to a TV. Page 41 Connecting to a TV or VCR 41 Playback on a TV Screen sound. Page 43 Connecting to a TV or VCR 43 Page 44 44 Connecting to a TV or VCR Copyright Signals. During playback. Page 45 Connecting to a Computer 45 Connecting to a Computer. PC Connection Diagrams Transferring Video Recordings IMPORTANT. You can transfer recordings to a computer The video transfer may. Page 47 Trouble 47. Additional Information Trouble If you have a problem with your camcorder, refer to this checklist. Consult. Page 48 48 Trouble Video noise appears on the TV When using the camcorder in a room where a TV.

Page 49 Trouble 49 Page 50 50 Trouble INPUT SIGNAL NOT the. Page 51 Do's and Don'ts 51 Do's and Don'ts Page 52 52 Do's and Don'ts The battery case Moving the camcorder rapidly between sudden. Page 55 Do's and Don'ts 55. Using the Camcorder Abroad. Power Sources. You can use the compact power adapter General Information Use of genuine Canon accessories is recommended. This product is designed to achieve excellent. Page 58 58 General Information. Shoulder Strap. You can attach a shoulder strap for more Pass the ends through. Page 59 General Information 59 System. Video Recording System 2 rotary heads, helical scanning DV system consumer digital VCR. Page 60 60 General Information. Power supply rated 7.4 V DC battery pack, 8.4 V DC compact power adapter. Power consumption. Page 61 General Information 61 Selecting the onscreen displays..... 37. Self timer.... Page 63 CANON INC. Canon Europa N.V. P.O. Box 2262, 1180 EG Amstelveen, the Netherlands. Canon UK Ltd. CCI Service Centre, Unit. Please check your inbox, and if you can't find it, check your spam folder to make sure it didn't end up there. Please also check your spam folder. The following symptoms may appear if the video heads become dirty even a little. Stop using it. We also recommend cleaning the video heads after use, before storing the camcorder. The Mains plug shall remain readily operable to disconnect the plug in case of an accident. Heat may build up, the plastic case may deform and it could result in electric shock or fire. Improper handling of this At the same time, your cooperation in the correct disposal of this product will contribute to the effective usage of natural resources. For more information about where you can drop off your waste equipment for recycling, please contact your local city office, waste authority, approved WEEE scheme or your household waste disposal service.

For more information regarding return and recycling of WEEE products, please visit Please read this manual carefully before you use the camcorder and retain it for future reference. Should your camcorder fail to operate correctly, refer to the Troubleshooting table POINTS TO CHECK Restrictions that apply if the function described is not Note that unless indicated otherwise, illustrations in this manual refer to the The list of Menu options in On menu screens, this is indicated by the joystick icon. You can display the joystick guide to remind you of the joystick's functions in each operating mode. In the manual, indicates that a function is available in the operating mode shown and indicates that the function is not available. When no operating mode icons are given, the function is available in all operating modes. When the tape reaches its end, the display changes to "END". In any case, you will be able to record on the tape the number of minutes that appears on the videocassette's label for example, 85 minutes. This is helpful to avoid scenes that are too short. Charge the battery pack before use. The indicator will stay on when the charging is completed. Lift the battery pack and then pull it out. This is not a malfunction. Continuously on Battery fully charged. Flashes approx. twice per second Battery over 50% charged. In cold places, the effective usage time of the battery will decrease. Connect a power source to the camcorder when replacing the backup battery to retain the settings. Rotating the panel 180 degrees is also useful if you wish to include yourself when recording with the self timer. Follow the additional operation guides that will appear on the screen such as the joystick icon, small arrows, etc.. Menu items not available will appear grayed out. The list of available languages depends on the region where you purchased the camcorder. The default setting is Paris or Singapore, depending on the region of purchase.

Select the time zone referring to the date and time displayed on the screen. Should your camcorder fail to operate correctly, refer to the Troubleshooting table 47. Conventions Used in the Manual IMPORTANT Precautions related to the camcorder's operation. NOTES Additional topics that complement the basic operating procedures. POINTS TO CHECK Restrictions that apply if the function dYou can display the joystick guide to remind you of the joystick's functions in each operating mode. Recording Playback EXP FOCUS About the Operating Modes The camcorder's operating mode is determined by the position of the switch. In the manual, indicates that a function is available in the operating mode shown and indicates that the function is not available. When no operating mode icons are gThe camcorder can be powered with a DC IN battery pack or directly

using the compact CHARGE terminal power adapter. Charge the battery pack indicator before use. Remove the battery terminal cover before attaching the battery 3 Connect the power cord Continuously on Battery fully charged. Rotating the panel 180 to open the lens cover. Follow the additional menu item currently selected. Menu operation guides that will appear on i. This Digital Video Camera is so easy and straight forward to use, anyone should be able to pick it up and start taking great movies. The fold out LCD has brightness and backlight adjustment so you'll always know exactly what you're shooting. It is easy to use, very accessible, affordable and fun whilst delivering great results. The MD120 delivers outstanding image quality with Canon's legendary optics; featuring 35x powerful optical zoom lens, 800k pixel CCD, DIG!C DV microprocessor and real widescreen recording. The joystick offers ease of use for operation and navigation and the compact design fits snugly in your hand. The Canon MD120 provides you with the easy way to capture great images of your memories.

Vous devez le déposer dans un lieu de ramassage prévu à cet effet, par exemple, un site de collecte officiel des équipements électriques et électroniques EEE en vue de leur recyclage ou un point d'échange de. Page 5 5 Table des matières Introduction Fr A propos de ce manuel. 7 Faites connaissance avec le caméscope Accessoires fournis. 9 Guide des composants. 10 Affichages sur l'écran. 12 Préparatifs Fonctions de base Enregistrement Enregistrement de séquences vidéo. 22 Utilisation du zoom. 23 Lecture Lecture de séquences vidéo. 24 Localisation de la fin du dernier enregistrement. 25 Agrandissement de l'image de lecture. 26 Fonctions avancées Listes des options de menu Menu FUNC. 27 Menus de configuration. Page 6 6 Ajustement de l'image exposition, mise au point et couleur Ajustement manuel de l'exposition. 35 Mise au point manuelle. 36 Balance des blancs. 37 Effets d'image. 38 Enregistrement et lecture audio Mode d'enregistrement audio. 39 Modes de lecture audio. 39 Autres fonctions Code de données. 41 Retardateur. 41 Effets numériques. 42 Connexions extérieures Connexion à un téléviseur ou un magnétoscope Diagrammes de connexion. Veuillez lire ce manuel attentivement avant d'utiliser le caméscope et le conserver à titre de référence future. Si votre caméscope ne fonctionne pas correctement, reportez-vous au tableau de la section Dépannage 51. Conventions utilisées dans le manuel Premiers réglages Premiers réglages Option de menu indiquée avec sa position par défaut Touches et commutateurs à utiliser Changement. Page 8 8 A propos du joystick et du guide du joystick Le mini joystick vous permet de commander diverses opérations du caméscope et de sélectionner et modifier les options des menus du caméscope. Poussez le joystick vers le haut, le bas, la gauche ou la droite, pour choisir une option ou changer un réglage. Appuyez sur le joystick lui-même pour valider un réglage ou confirmer une action. Sur.

Page 9 Faites connaissance avec le caméscope Accessoires fournis 9 Faites connaissance avec le caméscope Adaptateur secteur compact CA590E incluant le cordon d'alimentation Batterie d'alimentation BP2L5 Fr Pile bouton au lithium CR1616 Cable vidéo stéréo STV250N Introduction. Page 14 14 Mise en route Préparatifs 1 Mettez le caméscope hors tension. 2 Fixez la batterie d'alimentation sur Mise en route Mise en route Charge de la batterie d'alimentation Le caméscope peut être alimenté par une batterie ou directement à l'aide de l'adaptateur secteur compact. Chargez la batterie d'alimentation avant son utilisation. Retirez le cache-prise de la batterie avant d'attacher la batterie. Page 15 Mise en route 4 Branchez le cordon d'alimentation 5 sur une prise de courant. Connectez une alimentation électrique au caméscope lors du remplacement de la pile de secours pour conserver les réglages. Utilisez uniquement une cassette vidéo portant le. Page 17 Mise en route 4 Attendez que le logement de la cassette se rétracte automatiquement et fermez le couvercle du logement de la cassette. IMPORTANT N'interférez pas avec le logement de la cassette pendant son ouverture ou sa fermeture automatique, n'essayez pas non plus de fermer le couvercle avant que le logement de la cassette ne soit complètement rétracté. Faites attention de ne pas vous coincer les doigts dans le couvercle. Page 18 18 Utilisation des menus Utilisation des menus Utilisation des menus De nombreuses fonctions du caméscope peuvent être sélectionnées à partir du menu qui

apparaît quand vous appuyez sur la touche FUNC. FUNC. . Pour plus de détails sur les options de menu disponibles, reportez-vous aux Listes des options de menu 27. Le sujet peut contrôler l'image de l'écran LCD Retroéclairage de l'écran LCD Sélection d'une option du menu. Page 19 Utilisation des menus 4 Appuyez sur FUNC. Suivez les guides de sur fonctionnement supplémentaires qui s'affichent à l'écran comme par exemple l'icône du joystick, les petites flèches, etc..

3 4 5 6 1 Appuyez. Page 20 Premiers réglages 20 Premiers réglages Premiers réglages Changement des fuseaux horaires. La liste des langues disponibles dépend de la région où a été acheté le caméscope. Choix de langues A Anglais, allemand, espagnol, français, italien, polonais, roumain, turc, russe, ukrainien, arabe et perse. Choix de langues B Anglais, chinois simplifié, chinois. Préparatifs 3 et appuyez sur pour ouvrir les menus de réglage. Page 22 22 Enregistrement CONTROLE DE LA DERNIERE SCENE ENREGISTREE Fonctions de base Enregistrement Enregistrement Enregistrement de séquences vidéo Avant de commencer l'enregistrement Réalisez un enregistrement de contrôle pour vérifier si le caméscope fonctionne correctement. Au besoin, nettoyez les têtes vidéo 2. 8 EXP. FOCUS 1 Réglez le commutateur de mode sur. 2 Si le guide du joystick n'apparaît 3 1 Déplacez le commutateur du 2 3 couvercle de l'objectif. Page 23 Enregistrement NOTES Lors de l'enregistrement de séquences vidéo, essayez d'obtenir des images calmes et stables. Un mouvement excessif du caméscope pendant la prise de vue et l'utilisation intensive de zooms rapides et de panoramiques peut résulter dans des scènes qui remuent tout le temps et vacillent. Dans les cas extrêmes, la lecture de telles scènes peut entraîner des vertiges induits par les images. Si vous faites l'expérience d'une telle réaction. Page 24 24 Lecture Zoom optique Lecture Lecture 35x, 30x Déplacez le levier de zoom vers W pour faire un zoom arrière grand angle. Déplacez-le vers T pour faire un zoom avant téléobjectif. Vous pouvez aussi changer la vitesse du zoom 28. Vous pouvez sélectionner l'une des trois vitesses fixes de zoom ou une vitesse variable qui dépend de la manière d'activer le levier de zoom appuyez légèrement pour. Page 25 Lecture 6 Poussez le joystick vers pour arrêter la lecture. Page 26 26 Lecture Agrandissement de l'image de lecture Pendant la lecture, la séquence vidéo peut être agrandie jusqu'à 5 fois.

Page 27 Listes des options de menu Fonctions avancées Listes des options de menu Listes des options de menu Les options du menu non disponibles apparaissent en gris. Pour savoir comment sélectionner une option, reportez-vous à Utilisation des menus 18. Programmes d'enregistrement 33 Commutateur de mode. Lecture d'un enregistrement pour écran large les téléviseurs compatibles avec le système vidéo ID1 changent leur. Page 30 30 Listes des options de menu Le caméscope réduit le bruit de fond du vent lors d'un enregistrement en extérieur. Le filtre antivibrations ne peut pas être mis hors service quand le commutateur de mode est réglé sur. Utilisation des marqueurs n'affecte pas l'enregistrement sur la bande. Les affichages de fonctionnement de la bande apparaissent pendant 2 secondes. Il sert aussi de bip d'avertissement en cas de condition anormale. Page 39 Enregistrement et lecture audio Enregistrement et lecture audio Enregistrement et lecture audio 39 que le microphone soit le plus sensible possible 29. Page 40 40 Enregistrement et lecture audio Options. POUR ACTIVER UN. Page 44 Connexion à un téléviseur ou un magnétoscope 44 Connexion à un téléviseur ou un magnétoscope Connexions extérieures Connexion à un téléviseur ou un magnétoscope Diagrammes de connexion Mettez l'ensemble des périphériques hors tension lorsque vous procédez aux connexions et reportez-vous au manuel d'instructions du périphérique connecté. Connexion d'entrée par le signal à partir d'un téléviseur ou d'une autre source vidéo numérique avec une sortie DV IEEE1394. Page 47 Connexion à un téléviseur ou un magnétoscope 6 Arrêtez l'enregistrement quand la copie est terminée. Ce caméscope Arrêtez la lecture. Doublage Nous vous recommandons d'alimenter le caméscope avec l'adaptateur secteur compact. Lorsque vous connectez le caméscope à un. Page 48 48 Connexion à un téléviseur ou un magnétoscope IMPORTANT Les sections non enregistrées peuvent être enregistrées comme images anormales.

Si limage n'apparaît pas, débranchez le câble DV et rebranchez-le après quelques instants ou mettez le caméscope hors tension, puis de nouveau sous tension. Vous pouvez enregistrer uniquement des signaux vidéo au standard DV définition standard, mode SP ou LP à partir d'appareils portant le logo. Notez que des signaux. Prise sur le caméscope Câble de connexion 1 Connexion de sortie parcours du signal Prise sur. Page 50 50 Connexion à un ordinateur Transfert d'enregistrements vidéo Vous pouvez transférer des enregistrements sur un ordinateur à l'aide de la prise DV. Équipement et configuration minimum requis Un ordinateur équipé d'une prise IEEE1394 DV ou d'un tableau de capture IEEE1394 DV. Un câble DV utilisez le câble optionnel DV CV150F 4 broches 4 broches ou CV250F 4 broches 6 broches. Logiciel de montage vidéo. Le pilote approprié Un pilote est préinstallé sur. Page 51 En cas de problème 51 Informations additionnelles Dépannage En cas de problème Si vous avez un problème avec votre caméscope, reportez-vous à cette liste. Consultez votre revendeur ou un centre de service après-vente Canon si le problème persiste. Page 52 52 En cas de problème Problème Solution " " clignote sur l'écran. La batterie d'alimentation est déchargée. Remplacez ou chargez la batterie d'alimentation. 14 " " clignote sur l'écran. De la condensation a été détectée. Reportez-vous à la page indiquée. 58 "RETIRER LA CASSETTE" apparaît sur l'écran. Retirez et réinsérez la cassette. 16 Du bruit apparaît sur l'écran. Lors de l'utilisation du caméscope dans une pièce où se trouve un. Page 53 En cas de problème 53 Lecture Problème Solution Pendant la lecture, on entend le bruit de la vidéo. Les têtes vidéo sont sales. Nettoyez les têtes vidéo. 2 Appuyer sur la touche de lecture ne démarre pas la lecture. Insérez une cassette. 16 Réglez le caméscope sur La bande a atteint sa fin " Rembobinez la bande.. FIN" apparaît sur l'écran. 24 16 Aucun son ne sort du haut-parleur.

Page 55 A faire et à ne pas faire Précautions de manipulation 55 A faire et à ne pas faire Caméscope Fr DANGER. Page 56 56 A faire et à ne pas faire plusieurs batteries d'alimentation, réalisez ces précautions en même temps pour toutes les batteries d'alimentation. Réchauffez la batterie dans votre poche avant de l'utiliser. Utilisation d'autres piles. Page 58 58 A faire et à ne pas faire Condensation Faire passer brusquement le caméscope d'une pièce chaude à une pièce froide et vice-versa peut entraîner la formation de la condensation à l'intérieur du caméscope. Arrêtez d'utiliser le caméscope si de la condensation a été détectée. Continuer d'utiliser le caméscope peut l'endommager. La condensation peut se former dans les cas suivants quand le caméscope est amené d'une pièce climatisée dans. Page 61 Informations générales 61 Accessoires en option Fr Il est recommandé d'utiliser des accessoires Canon d'origine. Ce produit est conçu pour atteindre une excellente performance lorsqu'il est utilisé avec des accessoires Canon d'origine. Page 62 62 Informations générales Bandoulière Vous pouvez fixer la bandoulière pour plus de sécurité et une meilleure portabilité. Dragonne WS20 Utilisez-la pour une protection supplémentaire lors des prises de vues actives. Etui de transport souple SC2000 Un sac pour caméscope pratique avec des compartiments matelassés et beaucoup d'espace pour les. This document for download All trademarks and brands are the property of their respective owners.